

VACUUM FORMER

THE EASY-VAC™



The Easy-Vac Vacuum Former features a built-in vacuum and accommodates square or round material. Sturdy construction ensures years of reliable use.

Features:

- Hex Post- allows smooth up and down movement
- Reflective heating element casing- disperses the heat evenly over any thermoforming material
- Dial Timer- automatic shut-off prevents overheating
- Updated look and compact size with “no-worry” operation- makes it easier to store and use in your lab
- Noise Filter- quieter operation
- 2-Fuse Operation- keeps the machine from overloading the circuits

Power Supply- 110 – 220 V AC / 50 – 60 Hz

Heat Output- 550 W

Motor Output- 1250 W